



IMPORTANT

Required Blade Length
 $F = W - 1 7/8"$

SAFETY GLASS MAY
BE REQUIRED BY
LOCAL AUTHORITIES.

1

1. Ensure the frame is true and plumb **I**
2. Cut **A** Weatherstrips to width of frame = W
3. Drill holes as shown

W = Width of window opening
b = 1 1/2" Maximum
c = 8" Typical spacing between holes

2

NOTE:
Apply sealant to underside of the Weatherstrip for the whole length.

3

NOTE:
Apply sealant to all outside edges of Weatherstrip.

NOTE:
A Bottom Weatherstrip orientation.

4

NOTE: Do not over tighten the screws.

IMPORTANT!

Ensure the Frame and Gallery **C** are true and plumb **I**

IMPORTANT!

Leave 1/8" space at top for **A** top Weatherstrip.

E 1 1/4" Screws

OUTSIDE

NOTE: Orientation of Louvers

5

1. Ensure the Frame and the **A** top Weatherstrip are true and plumb **I**

Head NOTE:
Apply sealant to all outside edges of Gallery.

OUTSIDE

2. Fix **A** top Weatherstrip by repeating steps 2 and 3

6

1. Cut (both) **B** Weatherstrip inserts to length

2. Fit insert to head

X = Distance between Galleries

NOTE:
Install blades from the inside and check operation.